



Multi-Zone Compartment

If you are only able to select down to -6 then it is still set in fridge mode and needs to be changed to freezer mode.

1. To do this you will need to ensure that first you have the display showing the multi-zone selected.
2. Select the FN button
3. The Ice icon will appear next to the door
4. Select Ok

It will then change to a freezer, you will then be able to select temp between -18 & -24.

